

# Fiche Technique

*Théâtre du Crochetan*

*Monthey*

## Son

<i>Temps de réverbe</i>	salle pleine 1,2-1,3"		
<i>Régie</i>	Yamaha M7CL 48	1x	
<i>Amplification</i>	Lab Gruppen C48.4	2x	
	Electro-Voice Q66	1x	
<i>Traitement</i>	Electro-Voice DX 38	3x	
	Klark Teknik DN 370	1x	
	Lexicon LXP-1	2x	
<i>Facade</i>	Electro-Voice Plasma P2	2x	18"
	Electro-Voice Xi 1152	4x	15"+3"
	Electro-Voice Xi 1082	2x	8"+1"
	Electro-Voice Xi 1082	4x	8"+1"
<i>Retours</i>	Electro-Voice Zx5A	8x	15"
<i>Micros</i>	Electro-Voice PL 35	5x	Tom
	Electro-Voice PL 33	1x	Kick
	Electro-Voice PL 37	2x	OH
	Electro-Voice N/D 408	2x	
	Electro-Voice N/D 308	4x	
	Electro-Voice PL 80	4x	Voice
	Electro-Voice RE-2	3x	UHF
	Electro-Voice SM 91	3x	
<i>Appareil diffusion</i>	MD Sony	2x	(autopause)
	CD Sony	2x	(autopause)
<i>Intercom</i>	Central Clearcom	1x	
	Postes mobiles à câbles	6x	
<i>Alimentation sép.</i>	3x40 A à cour sur bornier	1x	
<i>Piano</i>	concert Steinway D	1x	
	1/2 queue Seiler	1x	
	droit Sauter	1x	

